

RADIAN[®] ANCHOR + MAGWELL

▷ FOR GLOCK[®] G43X[®] & G48[™]

INSTALLATION INSTRUCTIONS

STEP 01 | Slide the ANCHOR SCREW through the tapered opening at the top of the ANCHOR and down into the threaded hole. Rotate the ANCHOR SCREW until it's tapered head just makes contact with the matching tapered opening at the top of the ANCHOR. Back the screw off of the taper contact one half turn to ensure the ANCHOR can easily slip into the frame.

STEP 02 | Insert the ANCHOR and ANCHOR SCREW assembly into the grip cavity. Confirm that the assembly is fully seated against the bottom of the frame before proceeding to STEP 03.

NOTE | FAILURE TO FOLLOW STEP 03 EXPLICITLY MAY RESULT IN DAMAGE TO YOUR SERIALIZED FRAME.

STEP 03 | Place the frame into an upside-down orientation with the muzzle end of the firearm pointed in a safe direction. Triple check that the ANCHOR is fully seated against the bottom of the frame. Insert the provided 3/32" Allen key into the bottom of the ANCHOR screw, gently rotate the screw counterclockwise until you can just feel the taper contact. From that position torque the ANCHOR SCREW counterclockwise with the provided 3/32" Allen key 1-1/2 to 2 turns maximum!

STEP 04 | Insert the provided spring into the remaining hole in the bottom of the ANCHOR assembly, followed by the plunger tapered end up.

STEP 05 | Slide the MAGWELL over the firearm's magazine well until the female dovetail is indexed with the male dovetail on the ANCHOR.

STEP 06 | Using the provided DETENT TOOL, depress the plunger while putting rearward pressure on the MAGWELL until the plunger is covered by the MAGWELL. Remove the DETENT TOOL and apply rearward pressure to the MAGWELL until you hear the detent snap into place.

STEP 07 | To complete installation, place the front of the MAGWELL against a tabletop (with something to protect the table like cardboard) and press down hard on the rear of the frame causing the front tooth to bite into the front of the frame ensuring solid lock up.

STEP 08 | To remove, depress the plunger through the hole in the bottom of the MAGWELL while applying forward pressure to the MAGWELL. Slide the MAGWELL off of the frame. Using the provided 3/32" Allen key, rotate the ANCHOR SCREW clockwise to release the ANCHORS grip inside the frame. Remove the ANCHOR assembly from the frame.



@RADIANWEAPONS

CONTACT US

E SUPPORT@RADIANWEAPONS.COM
O 503.893.2987

875 NE KINGWOOD AVE
REDMOND, OR | 97756