

RADIAN® BACKSTRAP + MAGWELL

▷ FOR SIG SAUER® P365-XMACRO™

INSTALLATION INSTRUCTIONS

STEP 01 | Remove the OEM backstrap pin using a 1/8" punch or similar tool.

STEP 02 | Slide the OEM backstrap downwards until it separates from the grip module.

NOTE | The installation of the Radian P365 XMACRO Backstrap **does not** mirror the OEM backstrap installation. To avoid damaging your grip module, it is important to follow these instructions.

STEP 03 | Align the widened portion of the cavity on the Radian P365 XMACRO Backstrap with the bottom T-Lug on the grip module, this will allow the backstrap to drop down on the grip module. Then slide the backstrap up to engage on the "T-lugs". The backstrap should be flush with the bottom opening of the grip module.

STEP 04 | Place the grip module into an upside-down orientation and insert the provided plunger and spring (spring side first) into the cavity in the bottom of the Radian P365 XMACRO Backstrap.

STEP 05 | Slide the Radian P365 XMACRO Magwell over the firearm's magazine well following the groove at the bottom of the grip module until the female dovetail is indexed with the male dovetail on the Backstrap.

STEP 06 | Using the provided tool, depress the plunger while putting rearward pressure on the magwell. The magwell should lock into place completing the installation.

REMOVAL | To remove, depress the plunger through the hole in the bottom of the magwell while applying pressure away from the dovetail interface. Slide backstrap down until it bottoms out and pull away from the grip module.



@RADIANWEAPONS

CONTACT US

E SUPPORT@RADIANWEAPONS.COM
O 503.893.2987

875 NE KINGWOOD AVE
REDMOND, OR | 97756